Medium screw Long screw Short screw

1.Thrust the pulley into the base

2.Insert the air rod into the base

3. Medium screw for connecting backrest to connector

4.Long screws for connecting the seat cushion and the connecting parts

5.Fix The tray to the cushion with medium screw

6.Connect the tray to the Air Rod

7.Connect the armrests with short screws and washers

8.Put on a decorative cap

9.Medium screw for headrest and backrest connection